



# Basin heaters

## Spare parts guide

### Basin heaters

- Our factory-installed heaters keep the water temperature at 4°C and act as a simple and economical **anti-freeze measure for the basin water**.
- The heater package includes the **heaters**, a **thermostat** and a **low level cut out switch** to protect the heaters if the water level declines excessively.
- Standard electric heaters can handle ambient temperatures down to -18°C.
- All heaters and components are furnished with **weather-tight enclosures**.



#### Prevention tip !

Ensure the thermostat set point is properly set to prevent unnecessary energy consumption.

The setpoint should be  $\pm 4^{\circ}$  C. Improper set points may result in year round operation of the heater package, even during summer time, causing increased energy consumption.

**Want to benefit from a basin heater package?** Contact your [local BAC representative](#).

### Downloads

- [The SERVICE EXPERT for BAC Equipment](#)